



◀ **MCS-6561 39"**

top : Solid Red Cedar, Wooden Rosette Inlays
back/side : Rosewood
fingerboard : Bound Rosewood
binding : Maple + Wood purfling
tuners : Gold-plated, Agate Knobs
finish : Satin



◀ **MCS-6562 39"**

top : Solid Sitka Spruce +
wooden rosette
back / side : Sapele
fingerboard : Bound rosewood
binding : ABS +
faux abalone purfling
tuners : Gold-plated
finish : Satin



◀ **MCS-7560 39"**

top : Solid Sitka Spruce + wooden rosette
back / side : Sapele
fingerboard : Rosewood
binding : Maple + Wood purfling
tuners : Gold-plated, Agated Knobs
finish : High Gloss

Classical Guitar Series

Matwood®



- ◀ MC-6563 39"
top : Natural flamed maple
back / side : Natural flamed maple
fingerboard : Bound rosewood
binding : Maple + multiple ABS
tuners : Gold-plated, pearloid buttons
finish : Polished



- ◀ MC-6521C 39" Cutaway
top : Spruce
back / side : Sapele
fingerboard : Bound rosewood
binding : Double ABS
tuners : Gold-plated
finish : Polished
electronics : 3-band EQ



- ▶ MC-5525C 39" Cutaway
top : Cedar
back / side : Sapele
fingerboard : Rosewood + rosewood
binding
binding : Rosewood
tuners : Gold-plated
finish : High Gloss

- ▶ MC-5524 39"
top : Cedar
back / side : Sapele
fingerboard : Bound Rosewood
binding : Tortoiseshell ABS
tuners : Gold-plated
finish : High Gloss



- ◀ MC-6502 39"
top : Poplar + wooden rosette
back/side : Poplar
fingerboard : Rosewood
binding : Single ABS
tuners : Chromed
finish : Polished



- ◀ MC-6501 39"
top : Spruce
back/side : Agathis
fingerboard : Maple
binding : Single ABS
tuners : Chromed
finish : Glossy



- ◀ MC-6422 36"
top : Spruce +
wooden rosette
back / side : Sapele
fingerboard : Bound rosewood
binding : Single ABS
tuners : Chromed
finish : Satin



- ◀ MC-6500 39"
top : Agathis
back/side : Agathis
fingerboard : Plywood
binding : Single Black
tuners : Chromed
finish : Glossy



- ◀ MC-6400 36"
top : Akathis
back/side : Akathis
fingerboard : Plywood
binding : Single Black
tuners : Chromed
finish : Glossy



- ◀ MC-6300 34"
top : Agathis
back/side : Agathis
fingerboard : Plywood
tuners : Chromed
finish : Glossy



- ▶ **MCR-6533CEQ** 39" Round Back
top : Solid Englemann Spruce +
wooden rosette
back / side : Plastic
fingerboard : Bound Rosewood
binding : Multiple ABS
tuners : Gold-plated, pearloid buttons
finish : Polished
electronics : 3-band EQ



- ▼ **MCR-6531CEQ** 39" Round Back
top : Spruce
back / side : Plastic
fingerboard : Bound Rosewood
binding : Single ABS
tuners : Gold-plated
finish : Polished
electronics : 3-band EQ



- ◀ **MCR-6532CEQ** 39" Round Back
top : Spruce + wooden rosette
back / side : Plastic
fingerboard : Bound Rosewood
binding : Maple + wood purfling
tuners : Gold-plated, agate buttons
finish : Polished
electronics : 3-band EQ



Maxwood Musical Instruments

Address: No. 61 Qian Jin Road, Guangzhou, China

Factory Address: Bai Yun District, Guangdong, China

Phone: 86-137 2688 9014 Fax: 86-20-84245234 E-Mail: info@maxwood.cn